


## TRUNK



PIN	FUNCTION
P1	INTERIOR LIGHT POSITIVE
P2	INTERIOR LIGHT GROUND

PIN	FUNCTION
P1	BRAKE SW OUTPUT
P2	TRUNK LIGHT GROUND
P3	TRUNK LIGHT TAIL POWER

PIN	FUNCTION
A	LH SPEAKER POSITIVE
B	LH SPEAKER NEGATIVE
C	RH SPEAKER POSITIVE
D	RH SPEAKER NEGATIVE
E	TURN SIGNAL/HORN RELAY OUTPUT
F	GROUND
G	POWERLET FUSE OUTPUT
H	BRAKE SW OUTPUT